

Asm109x Raid Manager user manual

Click Asm109xRaidManager .app, will display the page (Figure 1). Fill the Mac user's password in Mac User Password fields, and click *login* button. After Confirm password correctly, app will show raid and disk information (Figure 2).

Mac User Password: login

Raid Device

Raid Information

RAID Type:

Status:

Capacity:

Firmware:

Figure 1

Mac User Password: login

Raid Device

ASMT109x - Fast Media

Raid Information

RAID Type: RAID 0

Status: GOOD

Capacity: 298 GB

Firmware: 131101000000

Status Manage Event log Advance Setting

Disk1

Model Name	Volume Size
ST320LM001 HN-M320MBB	298 GB
Serial Number	Status
S2XKJ9BC800035	GOOD

Disk2

Model Name	Volume Size
Serial Number	Status
	Empty

Disk3

Model Name	Volume Size
Serial Number	Status
	Empty

Figure 2




Figure 3

If your 109x device is GUI mode, you can change mode in manage subpages (Figure 3). Select mode type and click the *change mode* button.