

asm3142 firmware update SOP

Note: Program tool have to run it on real DOS environment, not Windows DOS mode

New firmware version : 211118_70_02_40.bin

1. Please unzip RE3142.A14.zip and copy RE3142.A14 folder to C:\
2. Boot into DOS
3. Please into C:\RE3142.A14
4. Type “ autoexec.bati.bat ” to start update firmware
5. When screen shown " Update firmware. . . .PASS!! " that's mean update finsh and successful.